



air scale for WINDOW

This airtightness scale indicates the perfect amount of air for a slow and smooth moving Sandpicture.

Place the scale into the corner of the frame and adjust the air to the scale.

more information at www.sandpicture.com

